J4 RTS
Changing the Lower Limit

Start

Is the Remote Multi or Single Channel?

— Multi → Select the Channel of the motor

Single

Move the blind away from the Upper and Lower limits

Hold the Up & Down Buttons

The motor jiggles

Press the down button continuosly until the lower limit is reached

The motor will continue to travel if the down button is held for more than 2 seconds

Press the Stop button when the desired limit is reached

Breifly press the Up button

The motor jiggles

End

Note:
If the new lower limit is missed in the process of changing the limit. Repeat in full, this changing limit flowchart.